





Towel Rail Installation

- review instructions carefully before installation
- installation should be completed by a suitably qualified person
- please dispose of packaging in a responsible manner


tools required


	Blanking Plug	x1/x3x
	Air Vent	x1
	Washer	x4
	Long Screw	x4
	Masonry Wall Plug	x4
	Spacer	x4
	Wall Support	x4
	Cap	x4
	Bracket Bush	x4
	Cross Bolt	x4
	Short Screw	x4

1


Apply PTFE tape(not supplied) to the blanking plug and insert them into the top left threaded holes. Apply PTFE tape(not supplied) to air vent and insert them into the top right threaded holes.






2



3





After installation . . .

- Use a screwdriver to open the air vent, open the valve and let the water rush into the towel warmer. Check all connections for leaks.
- Once water overflows from the air vent, there is no air in the tube.
- Use a screwdriver to close the air vent, turn on the valve and the towel warmer is ready for use.

After care . . .

- Classic towel warmers are made from steel with chrome plating, and should not be cleaned with corrosive or scouring cleaning agents.

Please note . . .

- This product can only be used at $PN \leq 0.8 \text{MPa}$ (8g/cm^2 , 8Bar), It should only be filled with water, and at a temperature below 100°C (212°F). See table below for installation requirements.
- If the temperature exceeds 48°C (or 120°F), please install a warning sign near the product to avoid burning and scolding accidents.

Fill ³ / ₄ Full	Pressure	Temperature	Comments
water only	$PN \leq 0.8 \text{Mpa}$	$0^\circ \text{C} < t \leq 100^\circ\text{C}$	If ambient temperature drops below 1°C , drain out the water to prevent freezing.